

8

Session VIII. Airborne LIDAR

N 9 1 - 2 4 1 4 3

Status of 2 Micron Laser Technology Program
Mark Storm, NASA Langley

October 17, 1990

Status of 2 Micron Laser Technology Program

Mark Storm*, ST Systems Corporation (STX)
28 Research Drive
Hampton, Virginia 23666

This paper describes the status of 2 micron lasers for windshear detection. Theoretical atmospheric and instrument system studies by Russell Tang and Rowland Bowles have demonstrated that the 2.1 micron Ho:YAG lasers can effectively measure windspeeds in both wet and dry conditions with accuracies of 1 m/sec. Two microns laser transmitter technology looks very promising in the near future but several technical questions remain. Ho:YAG laser would be small compact and efficient requiring little or no maintenance. Since the Ho:YAG laser is diode laser pumped and has no moving part, the lifetime of this laser should be directly related to the diode laser lifetimes which can perform in excess of 10,000 hours. Ho:YAG efficiencies of 3-12% are expected but laser demonstrations confirming the ability to Q-switch this laser are required. Coherent laser operation has been demonstrated for both CW and Q-switched lasers.

1577 Spring Hill Road
Suite 500
Vienna, VA 22180
(703) 827-6600

4400 Forbes Blvd.
Lanham, MD 20706
(301) 794-5000

9701 J. Philadelphia Ct.
Lanham, MD 20706
(301) 306-1100

109 Massachusetts Ave.
Lexington, MA 02173
(617) 862-0405

1900 Garden Road
Suite 130
Monterey, CA 93940
(408) 373-7292

Status of 2-Micron Laser Technology Program

Presented to the:

Third Combined Manufacturers' and Technologists'
Airborne Wind Shear Review Meeting, Hampton, Va.

October 17, 1990

Mark E. Storm
STX/NASA Langley

OUTLINE

- 1.0 Introduction**
 - Requirements for Coherent Lidar**
 - Laser approach**
- 2.0 Single-Frequency Ho:Tm:YAG**
 - Laser performance**
 - Frequency Tuning**
 - Heterodyne detection**
- 3.0 2-micron laser issues:**
 - Efficiency Considerations**
 - Crystal Spectroscopy**
- 4.0 Injection Seeding Experiment**
 - Coherent Technology Results**
- 5.0 Summary and Prospects for a Windshear Transmitter.**

Laser Requirements for a Windshear Transmitter


Single-Frequency, Q-switched

Laser energy: 5-10 mJ

Repetition rate: 150-300 Hz

Laser Bandwidth: 1.0 MHz

**Compact, Efficient, Reliable- 200+ hours of
maintenance free operation.**



WINDSHEAR TRANSMITTER

ORIGINAL PAGE IS
OF POOR QUALITY

RESEARCH GOAL:



SINGLE-MODE LASER FOR INJECTION LOCKING
OF Q-SWITCHED, 2-MICRON LASER.

APPROACH:

FABRY-PEROT
PLANO-PLANO
DIODE-LASER PUMPED

ACHIEVEMENTS:

- SINGLE-MODE LASING OF HO:TM:YAG
- 10 mW optical power at 2.091 microns
- 68% slope efficiency, QE.= 1.8, 4% optical-optical
- 31 GHz [4.5 Angstroms] Temperature Tuning
- Demonstrated Heterodyne Detection



SINGLE-FREQUENCY HO:TM:YAG LASER

SINGLE FREQUENCY HO:TM:YAG




Fig. 1. Multimode laser spectra of 2.5-mm thick Planoconvex Ho:Tm:YAG at two different laser output powers.





Fig. 2. Fluorescence spectra and single-longitudinal-mode lasing spectrum of a 1-mm thick Ho:Tm:YAG.

MULTIMODE LASING


SINGLE MODE LASING

SINGLE FREQUENCY HO:TM:YAG

FREQUENCY VS. TEMPERATURE
Ho:Tm:YAG



10 LOG SCALE




SELF-HETERODYNE
BEAT FREQUENCY

CRYSTAL TEMPERATURE [CELSIUS]

TEMPERATURE TUNING


HETERODYNE SIGNAL

Single-Frequency Laser Power



<Gaussian Fit Data>			<Cursor Location>	
	Vert	Horiz		
Correlation Coeff.	= 0.939	0.937	(X,Y) = (80,0)	
Peak Position	= 128	213	Profile Location	
Beam Dia. @ 1/e ² (nm)	= 5.234	5.279	X (Vert) = 215	
Percent of Peak	= 75.582	72.179	Y (Horiz) = 125	

Active Cursor: Contour




LEFT MOUSE BUTTON draws profile.

SINGLE-MODE SPACIAL PROFILE : TEM₀₀



ORIGINAL PAGE IS
OF POOR QUALITY


2 MICRON LASER EFFICIENCY




2-micron Laser Efficiency

	Present	Projected
Diode Laser	.50	.50
Optical Coupling	.80	.90
Absorption Effic.	.50	.65
Energy Transfer	.95	.95
Optical Extraction	.30	.60
Q-switching	.55	.80
Total Efficiency	.03	.13

Multi-mode Lasing Spectrum




Coherent Technology Inc.



Injection Locked, Q-switched, 2-micron Laser

Coherent Technology Inc.



2-Micron Accomplishments for Coherent Transmitter

-CW, single-frequency demonstrated.

Storm, Kane

-Pulsed, single frequency demonstrated in
flashlamp-pumped, injection control experiment.

Henderson

-Heterodyne detection demonstrated in
self-heterodyne experiment.

Storm


Future Demonstrations Necessary for Windshear Laser

-Efficient energy scaling to 10 mJ level
for Q-switched operation.

-Diode laser pumped

-100 Hz min. rep. rate


LASER DIODE PUMPED REMOTE SENSING DEVELOPMENT



Cr doped flashlamp
pumped laser



Tm:Ho
laser




Laser diode
array bank



Rare earth
eye - safe
laser

OUTPUT VS. ABSORBED ENERGY FOR ROOM TEMPERATURE
Cr:GSAG (Gd3 Sc2 Al3 O12) PUMPED RARE EARTH LASER



ABSORBED Cr:GSAG LASER ENERGY (mJ)

